

WHAT IS IN THE BOX?



- ✓ Two cans of fast drop resin, 500 g-1
- ✓ Set of 8 Vario Doses with red caps-2
- ✓ Set of 8 silver dispensing caps-3
- ✓ Set of 3 modular dispensing tubes-4
- ✓ Set of 6 dispensing needles-5

USER MANUAL & SETUP INSTRUCTION



1. Lay vinyl on a tray, use spray remount, magnetic stripes or masking tape to secure. Check flatness of the working tray with a level



2. Gently weed excess vinyl



3. Flatten the print with a pressure roller in order to prevent edge wings



4. Extend the telescopic cap by pulling top wings



5. Pull and remove the safety lock ring



6. Pour in the dispenser (resin first) equal amount of the two components using the print graduation or a separate precise digital scale



7. Close the dispenser with the cap (red) and lock



8. Shake the dispenser for 1 minute



9. Open the dispenser variodose



10. Apply the dispensing cap (silver)



11. Cut the top of the dispensing cap with scissors








12. Cut with scissors: 2 cm of clear tube and 1 cm of both black and red



13. Insert the three dispensing tubes in this order: 1) clear, 2) black, 3) red. Now you are ready to start doming the vinyl





LEGEND  self-adhesive vinyl thermo-adhesive  resin  doming path

