

Guidelines

 Vinyl/ Transfer













 Resin OK

 Resin Not OK.

 Needle Path

 OK



 NO





How to Use Poly Resin



TUTORIAL TS1



✓ TUTORIAL #1: DROP REGULAR SHAPED LABELS.



	 bar
1.20	2.0





✓ TUTORIAL #2: DROP IPOD GEL SKIN.



	 bar
1.20	2.4





	 bar
0.80	1.8


✓ TUTORIAL #3: DROP KEYCHAINS.

	 bar
1.20	1.6






✓ TUTORIAL #4: DROP LETTERING FOR FABRICS.

	 bar
1.10	1.0




✓ TUTORIAL #5: DROP LETTERING.



	 bar
1.10	0.8



✓ TUTORIAL #6: DROP IN & OUT LETTERING.

	 bar
1.10	0.8



	 bar
1.10	1.2

